PARTS DIAGRAM

P1	HANDLE
P2	CENTRE BODY
P3	FLAP
P4	FLAP SEAL
P5	SEAL CLIP
P6	M6 x WING NUT
P7	M6 x 50 CH SCREW
P8	WEIGHT
P9	M6 x 15 PAN HEAD SCREW
P10	M6 x 14 x 1.8 WASHER
P11	M6 VIBRATION WASHER
P12	M6 FULL NUT
P13	50mm WHEEL
P14	SCREW HOLDER
P15	M5 x 35 HEX. BOLT
P16	BRUSH SPRING
P17	BRUSH
P18	M5 FULL NUT
P19	LOCATING WASHER
P20	HALF BEARING
P21	30mm WHEEL
P22	M5 x 30 CH. HD. SCREW
P23	AXLE PIN
P24	CIRCLIP
P25	TORSION SPRING
P26	ADAPTOR CUFF 2 in. x 1.5 in.

